

		= 0		
Products :-	Notes:-	= C(eĸ
Cellcore HX B.	The appropriate specification of Cellcore and Heaveguard panels should be selected based upon the information provided in the relevant Cordek technical guidance.	Tel : 01403 799600		
	Cellcore panels should be installed on a smooth, flat, well compacted surface comprising of a sand / cement or concrete blinding.	Email: techsupport@cordek.com Drg. Title: Standard Pile Cap Detail - Cellcore HX B Drawn: SJP		
	Where necessary, joints between individual Cellcore panels should be sealed using Cordek formwork tape.			
	- Care should be taken not to surcharge the Cellcore panels with either reinforcement or concrete.			
		Date: June.2017	Scale: NTS	
		Drg No. ENG/GH/CELL/002 Rev 002		

Standard Detail